

NOTES:

1) SECURE ANCHORS AT BOTH ENDS INTO WALL. TIGHTEN CABLE USING TURNBUCKLES. ALL ABOVE HARDWARE AVAILABLE FROM ASI EXCEPT WALL ANCHORS. ON EXTREMELY LONG RUNS OF CABLE, INTERMEDIATE VERTICAL CABLE SUPPORT MAY BE REQUIRED.

TOLL FREE

2) 2) TIE-WIRE TO BE SNUGGED UP TIGHT TO CABLE SO TO PREVENT SLIPPAGE.

FAX