

**VIEW FROM BELOW**

SCALE: NA


**NOTES:**

1) CAUTION: DO NOT OVER TIGHTEN OR PUT EXCESSIVE FORCE ON GROMMETS, AS THIS MAY CAUSE BAFFLE FAILURE.

2) TIE-WIRE IS RECOMMENDED TO CONNECT DIRECTLY ABOVE GROMMET. AVOID ATTACHING AT ODD ANGLES, AS THIS CAUSES UNDO STRESS ON GROMMETS.


3) PREFERRED METHOD OF SUSPENSION.

4) TIE-WIRE TO BE SNUGGED TIGHT TO CABLE SO TO PREVENT SLIPPAGE.



**FRONT ELEVATION**

SCALE: NA



**SIDE ELEVATION**

SCALE: NA