


RSIC-GDS[®] KIT SOUND ISOLATION SYSTEM

RSIC-GDS Kit



- RSIC-GDS Motor Kit**
- RSIC-GDS Rail Kit**
- RSIC-GDS Complete Kit**



Acoustical Surfaces, Inc.
A Master Distributor for
PAC INTERNATIONAL, INC.



ACOUSTICAL | SURFACES, INC.

PAGE 1

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com

RSIC-GDS® KIT SOUND ISOLATION SYSTEM


RSIC-Garage Door Motor Kit Isolator Instructions

Installation Instructions:

- Close Garage Door.
- Measure distance from ceiling to top of garage door opener motor. Enter measurement here: (_____).
- Disconnect power from garage door opener motor.
- Support Garage Door Motor with ladder or stand.
- Disconnect metal brackets from the existing garage door motor.
- Disconnect metal brackets from ceiling.
- Install GARAGE DOOR MOTOR SILENCERS using the 1-½" flat washers and the 3" hex head screws (screws need to be installed into the joist).
- Trim 4" from the bottom of the metal support brackets to compensate for the 4" additional space that the GDS added.
- Bolt the metal brackets from step 2 to the GDS motor isolators using the ¾" bold, ¾" flat washers, and the 7/16" nyloc nut.
- Measure and adjust height of garage door rails using noted measurement taken in step 2.
- Reinstall the garage door motor to the metal brackets using the original hardware.
- Plug in your garage door opener motor.
- Test and adjust if needed.
- Repeat steps on other side.

RSIC-GDS Motor Kit Parts List:

2 ea RSIC-GDS Motor Isolators	2 ea ¾" bolts
4 ea 3-½" coarse thread screws	2 ea nyloc nuts
4 ea RSIC 1-½" Fender washers	4 ea ¾" washers




ACOUSTICAL | SURFACES, INC.

PAGE 2


Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com

RSIC-GDS[®] KIT SOUND ISOLATION SYSTEM

RSIC-Garage Door Motor Kit Isolator Instructions



BEFORE



AFTER



STOP NOISE

ACOUSTICAL | SURFACES, INC.




PAGE 3

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!

952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com

RSIC-GDS® KIT SOUND ISOLATION SYSTEM

RSIC-Garage Door Motor Kit Isolator Instructions



ACOUSTICAL | SURFACES, INC.

PAGE 4

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com

RSIC-GDS® KIT SOUND ISOLATION SYSTEM

RSIC-Garage Door Rail Kit Isolator Instructions

Installation Instructions: (This page only needed if you are adding the GDS garage door rail isolator clips to an already existing garage door opener system).

- Close Garage Door.
- Measure distance from ceiling to top of garage door opener motor. Enter measurement here: (_____).
- Disconnect power from garage door opener motor.
- Support Garage Door Rail with ladder or stand.
- Disconnect metal brackets from the existing garage door rail.
- Disconnect metal brackets from ceiling.
- Install GARAGE DOOR RAIL SILENCERS using the 1-1/2" flat washers and the 3" hex head screws (screws need to be installed into the joist)
- Trim 4" from the bottom of the metal support brackets to compensate for the 4" additional space that the GDS added.
- Bolt the metal brackets from step 2 to the GDS rail isolators using the 3/4" bold, 3/4" flat washers, and the 7/16" nyloc nut.
- Measure and adjust height of garage door rails using noted measurement taken in step 2.
- Reinstall the garage door rails to the metal brackets using the original hardware.
- Plug in your garage door opener motor.
- Test and adjust if needed.
- Repeat steps on other side.

RSIC-GDS Rail Kit Parts List:

4 ea RSIC-Rail isolators	4 ea 3/4" bolts
8 ea 3-1/2" coarse thread screws	4 ea nyloc nuts
8 ea RSIC-Retro Fender washers	8 ea 3/4" washers



ACOUSTICAL | SURFACES, INC.


PAGE 5

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com


™

RSIC-GDS® KIT SOUND ISOLATION SYSTEM

RSIC-Garage Door Motor Kit Isolator Instructions



BEFORE



AFTER



STOP NOISE

ACOUSTICAL | SURFACES, INC.

PAGE 6

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com

RSIC-GDS SOUND ISOLATION CLIP

RSIC-GDS Warranty



Members of the International Code Council

WARRANTY DISCLAIMER AND LIMITATION LANGUAGE

NO EXPRESS OR IMPLIED WARRANTIES

THERE IS NO WARRANTY, REPRESENTATION OR CONDITION OF ANY KIND, AND ANY WARRANTY, EXPRESS OR IMPLIED IS EXCLUDED AND DISCLAIMED, INCLUDING THE IMPLIED WARRANTIES OR MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow limitations on implied warranties, so the above limitation may not apply to you.

LIABILITY LIMITED TO RETURN OF PURCHASE PRICE

IT IS AGREED THAT SELLER'S LIABILITY AND PURCHASER'S SOLE REMEDY, WHETHER IN CONTRACT, UNDER ANY WARRANTY, IN TORT (INCLUDING NEGLIGENCE), IN STRICT LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE RETURN OF THE AMOUNT OF THE PURCHASE PRICE PAID BY PURCHASER, AND UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR ANY SPECIAL INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO, PERSONAL INJURY, PROPERTY DAMAGE TO OR LOSS OF EQUIPMENT, LOST PROFITS OR REVENUE, COSTS OF RENTING REPLACEMENTS AND OTHER ADDITIONAL EXPENSES, EVEN IF SELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE PRICE STATED FOR THE EQUIPMENT IS CONSIDERATION IN LIMITING THE SELLER'S LIABILITY AND PURCHASER'S REMEDY. Some states do not allow the exclusion or limitation incidental or consequential damages, so the above limitation or exclusion may not apply to you.

SELLER NOT LIABLE FOR PURCHASER'S NEGLIGENCE

SELLER WILL NOT BE LIABLE FOR ANY DAMAGES, LOSSES OR EXPENSES AS A RESULT OF PURCHASER'S NEGLIGENCE, WHETHER DEEMED ACTIVE OR PASSIVE AND WHETHER OR NOT ANY SUCH NEGLIGENCE IS THE SOLE CAUSE OF ANY SUCH DAMAGE, LOSS OR EXPENSE.

MODEL FOR DEMONSTRATION PURPOSED ONLY

THE MODEL OR SAMPLE SHOWN BY SELLER TO BUYER IS USED FOR DEMONSTRATION PURPOSES ONLY. THERE IS NO WARRANTY THAT THE GOODS AS DELIVERED SHALL CONFORM TO THE MODEL OR SAMPLE, AND CONFORMITY OF THE GOODS TO THE MODEL OR SAMPLE IS NOT PART OF THE BASIS OF THE BARGAIN BETWEEN SELLER AND BUYER.

NO WARRANTY OR COMPLIANCE WITH SAFETY CODE OR REGULATION

SELLER DOES NOT WARRANT THAT ANY OF THE GOODS SOLD WILL MEET OR COMPLY WITH THE REQUIREMENTS OF ANY SAFETY CODE, BUILDING OR DWELLING CODE, OR REGULATION OF ANY STATE, MUNICIPALITY OR OTHER JURISDICTION.

NEVADA LAW APPLIES

SELLER AND BUYER AGREE THAT ALL ASPECTS OF THIS TRANSACTION INCLUDING THE APPLICABLE STATUTE OF LIMITATIONS SHALL BE GOVERNED BY THE INTERNAL LAW OF THE STATE OF NEVADA, AND NOT THE LAWS OF CONFLICTS. This warranty gives you specific legal rights, and you may also have other rights which vary state to state.



ACOUSTICAL | SURFACES, INC.

PAGE 7

Celebrating Over 40 Years - SOUNDPROOFING, ACOUSTICS, NOISE & VIBRATION SPECIALISTS!
952.448.5300 | 800.448.0121 | sales@acousticalsurfaces.com | www.acousticalsurfaces.com